


## Instant light shaft

Ready-made skylight liner for easy and airtight completion on deck mounted skylights (Model ZZZ 234)



New

Bringing light to life



Prefabricated light shaft assembly kit.



**3.** Install mounting clips to skylight drywall groove.





**2.** Assemble moulding.



- 4. proper depth and join to moulding.
- No drywall, spackling, sanding and painting needed
- Works on all "box" type light shafts (Not flared)
- 16" Standard Depth (trim to actual on site)
- All others pieces are pre-cut to size to be site assembled
- 4" minimum spacing required around all sides if multiple skylights are installed



**\$250** (Bigger sizes: M02, M04, M06, M08, S01, S06)

**Must provide skylight size code when ordering.** Example order code: ZZZ 234 M02

## VELUX America Inc.